

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER RECEIVER
MUTE
SETUP
SEARCH
1/2/3/4/5
6/7/8/9/0
SIGNAL SELECT
CH. SELECT
DISPLAY
SURROUND
ROOM SETUP
T. EDIT
MASTER VOLUME+
MASTER VOLUME -
UP
DOWN
LEFT
RIGHT
ENTER
ADVANCED
SLEEP
TEST TONE
DIMMER
MPX
D. ACCESS

AUTO
DVD
DVR / VCR
FRONT
FM / AM
TV / SAT
CLASS
EON
RF ATT
TUNE+
TUNE -
ST -
ST+
SETUP ENTER

POWER RECEIVER, POWER, MUTE, SETARRIBA, MENU, SEARCH, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SIGNAL SELECT, SOURCE, CH SELECT, DISPLAY, SURROUND, ROOM SETARRIBA, T EDIT, MASTER VOLUME+, VOL+, MASTER VOLUME, VOL, ABAJO, IZQUIERDA, DERECHA, ENTER, ADVANCED, BACK, SLEEP, TEST TONE, TV/DTV, DIMMER, INFO, MPX, EPG, D ACCESS, FAV, AUTO, / NET TV, DVD, DVR / VCR, FRONT, FM / AM, TV / SAT, CLASS, EON, RF ATT, TUNE+, TUNE, ST+, SETARRIBA ENTER, .