

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
CLOCK
CLEAR
1/2/3/4/5
6/7/8/9/0
+10
∞ / RANDOM
SETUP
FAV ADD
VOLUME+
VOLUME-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
↻ / REPEAT
SLEEP
DBB / TONE
INFO
MODE / PROGRAM
FAV CALL

STOP
REW
PLAY / PAUSE
FWD
SEARCH
ANALOG IN
BLUETOOTH
CD
DIGITAL IN
INTERNET RADIO
MUSIC SERVER
ONLINE SERVER
TUNER
USB
TUNE+
TUNE-
CH+
CH-
DIMMER

POWER, MUTE, CLOCK, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0+1, / RANDOM, SETARRIBA, FAV ADD, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, / REPEAT, BACK, SLEEP, DBB / TONE, TV/DTV, INFO, MODE / PROGRAM, EPG, FAV CALL, FAV, STOP, REW, VERDE, PLAY / PAUSE, AMARILLO, FWD, AZUL, SEARCH, ANALOG IN, AZULTOOTH, DIGITAL IN, INTERNET RADIO, MUSIC SERVER, ONLINE SERVER, TUNER, USB, TUNE+, VOL+, TUNE, VOL, CH+, DIMMER, .