

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY / ON
MUTE
MENU / POPUP MENU
EXIT
1/2/3/4/5
6/7/8/9/0
FUNCTION
CLEAR
DISPLAY
RESOLUTION
TOOLS
SUBTITLE
VOL+/-
SKIP NEXT/PREV.
UP
DOWN
LEFT
RIGHT
ENTER
↵ / RETURN
SLEEP
CD / SACDC
DIMMER
TOP MENU
HOME MEDIA GALLERY

OPEN / CLOSE
PAUSE
STOP
USB REC
REW
PLAY
FWD
AUDIO
🏠 / HOME MENU
KEY LOCK
NET CONTENTS
CONTINUED
ANGLE
KARAOKE
MIC VOL+/-
SKIP SEARCH ⇨
REPEAT
A – B
SOUND RETRIEVER
SOUND
VIRTUAL 3D SOUND
RED / PROGRAM
GREEN / B.MARCK / RDS
YELLOW / ZOOM / PTY
BLUE / INDEX

STANDBY / ON, POWER, MUTE, MENU / POPARRIBA MENU, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION, / AV, CLEAR, DISPLAY, RESOLUTION, TOOLS, SUBTITLE, VOL+, VOL, SKIP NEXT/PREV, P+, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, SLEEP, CD / SACDC, TV/DTV, DIMMER, INFO, TOP MENU, EPG, HOME MEDIA GALLERY, FAV, OPEN / CLOSE, PAUSE, STOP, USB REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, / HOME MENU, KEY LOCK, NET CONTENTS, CONTINUED, ANGLE, KARAOKE, MIC VOL+, VOL+, SKIP SEARCH, REPEAT, SOUND RETRIEVER, SOUND, VIRTUAL 3D SOUND, ROJO / PROGRAM, VERDE / BMARCK / RDS, AMARILLO / ZOOM / PTY, AZUL / INDEX, .