

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
⏻ / AUDIO
🏠 / HOME
CLEAR
1/2/3/4/5
6/7/8/9/0
🔍 / SEARCH
DISPLAY
ZOOM
SUBTITLE ON/OFF
📄 / SUBTITLE
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
🔄 / RETURN
DISC MENU
TITLE / POP – UP
RESOLUTION
MARKER
OPEN / CLOSE
PAUSE

STOP
SCAN REW
PLAY
SCAN FWD
REPEAT
RED / A
GREEN / B
YELLOW / C
BLUE / D

POWER, / AUDIO, MUTE, / HOME, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / SEARCH, DISPLAY, ZOOM, SUBTITLE ON/OFF, / SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, DISC MENU, TV/DTV, TITLE / POP, INFO, RESOLUTION, EPG, MARKER, FAV, OPEN / CLOSE, PAUSE, STOP, SCAN REW, VERDE, PLAY, AMARILLO, SCAN FWD, AZUL, REPEAT, ROJO / A, ROJO, VERDE / B, AMARILLO / C, AZUL / D, .