

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



AD
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
FUNCTION MENU
PROG / CHECK
INTERNET
/ LAST VIEW
SETUP
/ TEXT
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
/ BACK / RETURN
TIME SLIP
RADIO / TV
i / STATUS
GUIDE
DIRECT NAVIGATOR

NETFLIX
PAUSE
STOP
REC
REW
PLAY / x13
FWD
/ STTL
CH+
CH -
MANUAL SKIP +60s
MAUAL SKIP -10s
DEL
CHAPTER
DRIVE SELECT
RED
GREEN
YELLOW
BLUE

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION MENU, SOURCE, PROG / CHECK, INTERNET, / LAST VIEW, SETARRIBA, / TEXT, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, / BACK / RETURN, BACK, TIME SLIP, SLEEP, RADIO / TV, TV/DTV, i / STATUS, INFO, GUIDE, EPG, DIRECT NAVIGATOR, FAV, NETFLIX, / NET TV, PAUSE, STOP, / SMART, REC, ROJO, REW, VERDE, PLAY / x13, AMARILLO, FWD, AZUL, / STTL, CH+, MANUAL SKIP +60s, MAUAL SKIP, 10s, DEL, SHFIT+BACK, CHAPTER, DRIVE SELECT, .