

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY
MUTE
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
V - MODE
10+
DISPLAY
ZOOM
SETUP
SUBTITLE
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
STEP
P / N
TITLE

PROG
MARK
EJECT
STOP
F. REV
PLAY / PAUSE
F. FWD
LANGUAGE
SEARCH
SHUFFLE
PBC
ANGLE
SLOW
CHANNEL
/ REPEAT
/ A - B
RESET

STANDBY, POWER, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, MODE, SOURCE, 10+, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, STEP, SLEEP, P / N, TV/DTV, TITLE, INFO, PROG, EPG, MARK, FAV, EJECT, / NET TV, STOP, / SMART, F REV, VERDE, PLAY / PAUSE, AMARILLO, F FWD, AZUL, LANGUAGE, SEARCH, SHUFFLE, PBC, ANGLE, SLOW, CHANNEL, / REPEAT, / A, RESET, .