

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.



	EJECT
MUTE	STOP
SETTINGS	REW
CLEAR	PLAY / PAUSE
1/2/3/4/5	FWD
6/7/8/9/0	BRIDGE
FM MODE	DIGITAL IN
RANDOM	DISC
DISPLAY	LINE IN
TIME	RADIO
CHECK	USB
AUTO CHECK	PRESET / FOLDER+
VOLUME LEVEL+	PRESET / FOLDER -
VOLUME LEVEL -	
SKIP NEXT	
SKIP PREV	
UP	
DOWN	
LEFT	
RIGHT	
ENTER	
BACK	
SLEEP	
INFO	
PROG / MEM	

POWER, MUTE, SETTINGS, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FM MODE, / SOURCE, RANDOM, DISPLAY, TIME, CHECK, AUTO CHECK, VOLUME LEVEL+, VOL+, VOLUME LEVEL, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, SLEEP, INFO, PROG / MEM, EPG, EJECT, STOP, REW, VERDE, PLAY / PAUSE, AMARILLO, FWD, AZUL, BRIDGE, DIGITAL IN, DISC, LINE IN, RADIO, USB, PRESET / FOLDER+, PRESET / FOLDER, .