

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
LIST
/ HOME
SIZE / MUOSE
MIX
TTX
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
SLEEP
SUB. PG
INFO

EPG SET
FAV
ASPECT
FREEZE
HOLD / REFRESH
RED
GREEN
YELLOW
BLUE
AUDIO
CANCEL
/ APP
REVEAL
SOUND
PICTURE
SUBTITLE
SKIP NEXT
SKIP PREV
INDEX
CAPTURE
STOP
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, LIST, / HOME, SIZE / MUOSE, MIX, TTX, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, SUB PG, TV/DTV, INFO, EPG SET, EPG, FAV, ASPECT, / NET TV, FREEZE, HOLD / REFRESH, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, CANCEL, / APP, REVEAL, SOUND, PICTURE, SUBTITLE, SKIP NEXT, SKIP PREV, INDEX, CAPTURE, STOP, REW, PLAY / PAUSE, FWD, .