

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
 El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
 Revise que localiza todas las funciones que necesita antes de realizar la compra.



ON / STAND BY
MUTE
MENU / PBC
SLOW
1/2/3/4/5
6/7/8/9/0
FUNCTION
+10
DISPLAY
ZOOM
SETUP
SUBTITLE
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
NTSC / PAL
TITLE

PROGRAM
LANGUAGE
OPEN / CLOSE
STOP
REW
PLAY / PAUSE
FWD
AUDIO
MODE
LISTENING
DIRECT
ANGLE
A - B
EQ
REPEAT
STEP
ST / MO
DIMMER
MEMORY
I/P SCAN

ON / STAND BY, POWER, MUTE, MENU / PBC, MENU, SLOW, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION, / SOURCE, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, VOLUME+, VOL+, VOLUEME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, NTSC / PAL, TV/DTV, TITLE, INFO, PROGRAM, EPG, LANGUAGE, FAV, OPEN / CLOSE, STOP, REW, VERDE, PLAY / PAUSE, AMARILLO, FWD, AZUL, AUDIO, MODE, / SOURCE, LISTENING, DIRECT, ANGLE, REPEAT, STEP, ST / MO, DIMMER, MEMORY, I/P SCAN, .