

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



ON / STAN - BY
MUTE
MENU / PBC
LISTENING
1/2/3/4/5
6/7/8/9/0
MODE
>10
DISPLAY
ZOOM
SETUP
SUBTITLE
ADJ / VOL+
ADJ / VOL -
TUNING / SKIP NEXT
TUNING / SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
ST / MO
TITLE

PROG
LANGUGE
OPEN / CLOSE
STOP
REW
PLAY / PAUSE
FWD
AUDIO
DVD
TUNER
AUX
DIRECT
A - B
ANGLE
SLOW / MEMORY
REPEAT
STEP
NTSC / PAL

ON / STAN, POWER, MUTE, MENU / PBC, MENU, LISTENING, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0MODE, / SOURCE, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, ADJ / VOL+, VOL+, ADJ / VOL, VOL, TUNING / SKIP NEXT, TUNING / SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, ST / MO, TV/DTV, TITLE, INFO, PROG, EPG, LANGUGE, FAV, OPEN / CLOSE, STOP, REW, VERDE, PLAY / PAUSE, AMARILLO, FWD, AZUL, AUDIO, DVD, TUNER, AUX, DIRECT, ANGLE, SLOW / MEMORY, REPEAT, STEP, NTSC / PAL, .