FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
AUDIO
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
SHUFFLE
HOME
ANGLE
SETUP
SUBTITLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
STATUS
PIP
ON SCREEN
TOP MENU
EJECT
PAUSE

STOP
REW
PLAY
FWD
2 nd AUDIO
SEARCH
REPEAT
A – B
RED / PROGRAM
GREEN / MARKER
YELLOW / DIGEST
BLUE / ZOOM

POWER, AUDIO, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SHUFFLE, HOME, ANGLE, SETARRIBA, SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, STATUS, SLEEP, PIP, TV/DTV, ON SCREEN, INFO, TOP MENU, FAV, EJECT, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, SEARCH, REPEAT, ROJO / PROGRAM, SHFIT+ROJO, VERDE / MARKER, AMARILLO / DIGEST, SHFIT+AMARILLO, AZUL / ZOOM, .