FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
/ MENU/EXIT
1/2/3/4/5
6/7/8/9/0
/ SOURCE
/ CH RTN
/ FULL SCREEN
/ SNAPSHOT
/ PIP
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
/ BACK
SLEEP
TIMESHIFT
WAKE UP
/ EPG

•
RED / TV
GREEN / VIDEO
YELLOW / MUSIC
BLUE / PICTURE
/ AUDIO
SKIP NEXT
SKIP PREV
STOP
REC
REW
PLAY/PAUSE
STOP

POWER, MUTE, / MENU/EXIT, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / SOURCE, / SOURCE, / CH RTN, / FULL SCREEN, / SNAPSHOT, / PIP, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, / BACK, BACK, SLEEP, TIMESHIFT, TV/DTV, WAKE ARRIBA, INFO, / EPG, EPG, FAV, ROJO / TV, ROJO, VERDE / VIDEO, VERDE, AMARILLO / MUSIC, AMARILLO, AZUL / PICTURE, AZUL, / AUDIO, SKIP NEXT, SKIP PREV, STOP, REC, REW, PLAY/PAUSE, SHFIT+AMARILLO, .