FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
1/2/3/4/5
6/7/8/9/0
DISPLAY
D. TUNING
AMP. MENU
VOL+
VOL -
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
⊕
/ RETURN / EXIT
MEMORY
PAUSE
STOP
REW
PLAY
FWD
BD

DM PORT.
DVD
SA CD / CD
SAT / CATV
TUNER
TV
VIDEO
PROG+
PROG -
ENTER

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DISPLAY, D TUNING, AMP MENU, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, / RETURN / EXIT, BACK, MEMORY, EPG, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, DM PORT, DVD, SHIT+3, SA CD / CD, SAT / CATV, TUNER, VIDEO, PROG+, PROG, ENTER, Keys Functions LAYOUT, Code 57, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .