FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER RECEIVER
MUTE
HOME MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
IPOD CTRL
TOP MENU
DISPLAY
MCACC/POP UP MNEU
SETUP/TOOLS
SUBTITLE
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP/TUNE+
DOWN/TUNE -
LEFT/ST -
RIGHT/ST+
ENTER
IPOD REPEAT
SOUD RETREIVER
T.EDIT/OUTPUT RES.
SOUND/VIDEO SELECT

CLASS/HOME MEDIA GALL.
IPOD SHUFFLE
PAUSE
STOP
REW
PLAY
FWD
AUDIO
HDMI 1-2
IPOD
LINE
TUNER FM/AM
TV
SURROUND
ADV SURR.
ANGLE

POWER RECEIVER, POWER, MUTE, HOME MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0IPOD CTRL, / SOURCE, TOP MENU, DISPLAY, MCACC/POP ARRIBA MNEU, SETARRIBA/TOOLS, SUBTITLE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ARRIBA/TUNE+, ABAJO/TUNE, ABAJO, IZQUIERDA/ST, IZQUIERDA, DERECHA/ST+, DERECHA, ENTER, IPOD REPEAT, BACK, SOUD RETREIVER, SLEEP, TEDIT/OUTPUT RES, TV/DTV, SOUND/VIDEO SELECT, INFO, CLASS/HOME MEDIA GALL, EPG, IPOD SHUFFLE, FAV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, HDMI 1, IPOD, LINE, TUNER FM/AM, SURROUND, ADV SURR, ANGLE, .