FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
⌂
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
CH LIST
RAKUTEN TV
☰
TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
⮌
GUIDE
NETFLIX
YOUTUBE
PRIME VIDEO

RED
GREEN
YELLOW
BLUE
DEEZER
MEDIASET INFINITY
SUBTITLE
CHILI
TIMVISION
RAI PLAY
PLAY/PAUSE

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, CH LIST, RAKUTEN TV, TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, GUIDE, EPG, NETFLIX, / NET TV, YOUTUBE, PRIME VIDEO, / SMART, ROJO, VERDE, AMARILLO, AZUL, DEEZER, MEDIASET INFINITY, SUBTITLE, CHILI, TIMVISION, SLEEP, RAI PLAY, TV/DTV, PLAY/PAUSE, Keys Functions LAYOUT, Code 4315, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .