FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
☰
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
CH.LIST
⌂
TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
↩
RAKUTEN TV
⊞
GUIDE
MEDIA
NETFLIX

YOUTUBE
PRIME VIDEO
RED
GREEN
YELLOW
BLUE
SUBTITLE
PAUSE
STOP
REW
PLAY
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, CHLIST, TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, RAKUTEN TV, TV/DTV, INFO, GUIDE, EPG, MEDIA, FAV, NETFLIX, / NET TV, YOUTUBE, PRIME VIDEO, / SMART, ROJO, VERDE, AMARILLO, AZUL, SUBTITLE, PAUSE, STOP, REW, PLAY, FWD, Keys Functions LAYOUT, Code, 651, 0HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .