FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
AUDIO
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
FUNCTION MENU
INTERNET
/ LAST VIEW
/ TEXT
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
/ BACK / RETURN
RADIO / TV
i / STATUS
GUIDE
VIDEO MENU
NETFLIX
PAUSE
STOP

REC
REW
PLAY / x13
FWD
INPUT SELECT
/ STTL
CH+
CH -
MANUAL SKIP +60s
MAUAL SKIP -10s
DRIVE SELECT
RED
GREEN
YELLOW
BLUE

POWER, AUDIO, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION MENU, / SOURCE, INTERNET, / LAST VIEW, / TEXT, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, / BACK / RETURN, BACK, RADIO / TV, TV/DTV, i / STATUS, INFO, GUIDE, EPG, VIDEO MENU, FAV, NETFLIX, / NET TV, PAUSE, STOP, / SMART, REC, ROJO, REW, VERDE, PLAY / x13, AMARILLO, FWD, AZUL, INPUT SELECT, / STTL, CH+, MANUAL SKIP +60s, MAUAL SKIP, 10s, DRIVE SELECT, .