FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
MENU
1/2/3/4/5
6/7/8/9/0
SPEED
VOLUME+
VOLUME -
INDEX/SKIP NEXT
INDEX/SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
TIMER
PAUSE
STOP
REC
REW
PLAY
FWD
CH+
CH -
TRK/V-LOCK/CH+

TRK/V-LOCK/CH -
ON+
ON -
OFF -
OFF+
DATE -
DATE+

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SPEED, VOLUME+, VOL+, VOLUME, VOL, INDEX/SKIP NEXT, INDEX/SKIP PREV, ABAJO, IZQUIERDA, DERECHA, TIMER, SLEEP, PAUSE, STOP, / SMART, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, CH+, VOL+, VOL, TRK/V, LOCK/CH+, LOCK/CH, ON+, OFF, OFF+, DATE, DATE+, SHFIT+AZUL, Keys Functions LAYOUT, Code, 691, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .