FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻ ON
1/2/3/4/5
6/7/8/9/0
FUNCTION
BASS
VOL+
VOL -
SKIP NEXT
SKIP PREV
TUNING/FILE -
TUNING/FILE+
REPEAT/FM MODE
SLEEP
RANDOM
FOLDER/PRESET
MEMORY
SOUND
OPEN/CLOSE
STOP
USB REC/PAUSE
CD PLAY/PAUSE
USB/PLAY/PAUSE
SD REC/PAUSE
SD PLAY/PAUSE

ORIGINAL, SARRIBAERIOR, POWER, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION, / SOURCE, BASS, VOL+, VOL, SKIP NEXT, SKIP PREV, TUNING/FILE, IZQUIERDA, TUNING/FILE+, DERECHA, REPEAT/FM MODE, BACK, SLEEP, RANDOM, TV/DTV, FOLDER/PRESET, INFO, MEMORY, EPG, SOUND, FAV, OPEN/CLOSE, / NET TV, STOP, / SMART, USB REC/PAUSE, ROJO, CD PLAY/PAUSE, AMARILLO, USB/PLAY/PAUSE, BLU, SD REC/PAUSE, SD PLAY/PAUSE, Keys Functions LAYOUT, Code, 693, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .