FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
DVI/HDMI
+10
OSD
GOTO
PAL/NTSC
SUBTITLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
SELECT
RETURN
SLOW
CD MODE
INFO
ANGLE
MODE

EJECT
PAUSE
STOP
SCAN REW
PLAY
SCAN FWD
AUDIO
ZOOM
SETUP
REPEAT
A – B

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DVI/HDMI, / SOURCE, OSD, GOTO, PAL/NTSC, SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, SELECT, RETURN, BACK, SLOW, SLEEP, CD MODE, TV/DTV, INFO, ANGLE, EPG, MODE, FAV, EJECT, / NET TV, PAUSE, STOP, / SMART, SCAN REW, VERDE, PLAY, AMARILLO, SCAN FWD, AZUL, AUDIO, ZOOM, SETARRIBA, REPEAT, Keys Functions LAYOUT, Code, 694, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .