FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
LIST
HOME
⁘
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
BACK
GOOGLE PLAY
INFO
GUIDE
NETFLIX

YOUTUBE
PRIME VIDEO
RED
GREEN
YELLOW
BLUE
AUDIO
SUBT
STOP
REC
REW
PLAY/PAUSE
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, LIST, HOME, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, GOOGLE PLAY, TV/DTV, INFO, GUIDE, EPG, NETFLIX, / NET TV, YOUTUBE, PRIME VIDEO, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, SUBT, STOP, REC, REW, PLAY/PAUSE, FWD, Keys Functions LAYOUT, Code, 697, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .