FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON/STANDBY
AUDIO
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
USB
+10
DISPLAY
ZOOM
SETUP
SUBTITLE/MP3 CONV.
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLOW
HDMI
MEMORY
A – B RPT
OPEN/CLOSE

PAUSE/STEP
STOP
REW
PLAY
FWD
TOP MENU
SEARCH
DVD
PBC
E.A.M.
ANGLE
E.P.M.
NAVI
PLAY MODE

ORIGINAL, SARRIBAERIOR, ON/STANDBY, POWER, AUDIO, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0USB, / SOURCE, DISPLAY, ZOOM, SETARRIBA, SUBTITLE/MP3 CONV, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLOW, SLEEP, HDMI, TV/DTV, MEMORY, EPG, B RPT, FAV, OPEN/CLOSE, / NET TV, PAUSE/STEP, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, TOP MENU, SEARCH, DVD, PBC, EAM, ANGLE, EPM, NAVI, INFO, PLAY MODE, Keys Functions LAYOUT, Code, 698, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .