FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
⊖
LIST
HOME
P.MODE
S.MODE
TEXT
VOL+
VOL -
P+
P -
UP
DOWN
LEFT
RIGHT
OK
BACK
TV
i+
GUIDE

MEDIA
NETFLIX
YOUTUBE
APPS
RED
GREEN
YELLOW
BLUE
SUBTITLE
SKIP NEXT
SKIP PREV
PAUSE
STOP
REW
PLAY
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / SOURCE, LIST, HOME, PMODE, SMODE, TEXT, VOL+, VOL, ABAJO, IZQUIERDA, DERECHA, BACK, TV/DTV, INFO, GUIDE, EPG, MEDIA, FAV, NETFLIX, / NET TV, YOUTUBE, APPS, / SMART, ROJO, VERDE, AMARILLO, AZUL, SUBTITLE, SKIP NEXT, SKIP PREV, PAUSE, STOP, REW, PLAY, FWD, Keys Functions LAYOUT, Code, 717, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .