FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
🏠
▦ / MEDIA
◯◯ / I/II
⚙
TXT
VOL+
VOL -
P+
P -
UP
DOWN
LEFT
RIGHT
OK
BACK
SLEEP
DTV
INFO

GUIDE
FAV
NETFLIX
YOUTUBE
e
RED
GREEN
YELLOW
/ BLUE
P.MODE
S.MODE
SUBT
STOP
REC
REW
PLAY/PAUSE
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, / MEDIA, / I/II, TXT, VOL+, VOL, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, DTV, TV/DTV, INFO, GUIDE, EPG, FAV, NETFLIX, / NET TV, YOUTUBE, / SMART, ROJO, VERDE, AMARILLO, AZUL, PMODE, SMODE, SUBT, STOP, REC, REW, PLAY/PAUSE, FWD, Keys Functions LAYOUT, Code, 726, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .