FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
DISC MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
/ RADIO&INPUT
OPTICAL
HOME
SOUND EFFECT
SPEAKER LEVEL
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP/PRESET+
DOWN/PRESET -
LEFT/TUNING -
RIGHT/TUNING+
ENTER
RETURN
SLEEP
MUSIC ID
INFO/DISPLAY
TITLE/POPUP

MARKER
OPEN/CLOSE
PAUSE
STOP
REC
REW
PLAY
FWD
SEARCH
REPEAT
RED
GREEN
YELLOW
BLUE/MONO-STEREO

ORIGINAL, SARRIBAERIOR, POWER, MUTE, DISC MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / RADIOINPUT, / SOURCE, OPTICAL, HOME, SOUND EFFECT, SPEAKER LEVEL, VOL+, VOL, SKIP NEXT, SKIP PREV, /PRESET+, ABAJO, /PRESET, IZQUIERDA, /TUNING, DERECHA, /TUNING+, ENTER, RETURN, BACK, SLEEP, MUSIC ID, TV/DTV, INFO/DISPLAY, INFO, TITLE/POPARRIBA, EPG, MARKER, FAV, OPEN/CLOSE, NET, PAUSE, SMART, TUBE, STOP, VIDEO, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, SEARCH, REPEAT, AZUL/MONO, STEREO, Keys Functions LAYOUT, Code, 734, 0HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .