FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY
MUTE
MENU
1/2/3/4/5
6/7/8/9/0
+10
DISPLAY
ZOOM
TITLE
SUBTITLE
VOL+
VOL-
UP
DOWN
LEFT
RIGHT
OK
P/I
VOCAL-ASSIST
PROGRAM
PBC
RED/EDIT
GREEN/COPY
YELLOW/DELETE
BLUE/TARGET

SETUP
RANDOM
ANGLE
LANGUAGE
SLOW
RESUME
SKIP PREV.
SKIP NEXT
REPEAT
A-B
SEARCH
OPEN/CLOSE
PAUSE
STOP
REW
PLAY
FWD

STANDBY, POWER, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0+1, DISPLAY, ZOOM, TITLE, SUBTITLE, VOL+, VOL, ABAJO, IZQUIERDA, DERECHA, P/I, TV/DTV, VOCAL, ASSIST, INFO, PROGRAM, EPG, PBC, FAV, ROJO/EDIT, ROJO, VERDE/COPY, VERDE, AMARILLO/DELETE, AMARILLO, AZUL/TARGET, AZUL, SETARRIBA, RANDOM, ANGLE, LANGUAGE, SLOW, RESUME, SKIP PREV, SKIP NEXT, REPEAT, BACK, SLEEP, SEARCH, OPEN/CLOSE, PAUSE, STOP, REW, PLAY, FWD, .