FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
M / MENU
← / EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
-/--
TV STATUS
/ SLEEP
SIZE
TEXT
VOL+
VOL-
P+
P-
UP
DOWN
LEFT
RIGHT
OK
BACK
DTV
INFO
EPG

APP
STILL
RED / DELETE
GREEN / SKIP
YELLOW / INSERT
BLUE / REPLACE
MTS /
DTVM
MON
PICTURE
SOUND
CTRL
PC
FOCUS
/ PREPG
PIP
SKIP PREV.
SKIP NEXT
/ TIME
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, MUTE, M / MENU, MENU, / EXIT, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / AV, TV STATUS, / SLEEP, SIZE, TEXT, VOL+, VOL, ABAJO, IZQUIERDA, DERECHA, BACK, DTV, TV/DTV, INFO, EPG, APP, FAV, STILL, ROJO / DELETE, ROJO, VERDE / SKIP, VERDE, AMARILLO / INSERT, AMARILLO, AZUL / REPLACE, AZUL, MTS /, DTVM, MON, PICTURE, SOUND, CTRL, FOCUS, / PREPG, PIP, SKIP PREV, SKIP NEXT, / TIME, PAUSE, STOP, REC, REW, PLAY, FWD, .