FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
AUDIO
POP-UP / MENU
TOP MENU
1/2/3/4/5
6/7/8/9/0
GOTO
DISPLAY
NETFLIX
ANGLE
SUB
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
OK
RETURN
HOME
OPEN / CLOSE
PAUSE
STOP
REV.
PLAY

FWD
2nd AUDIO
CLEAR
PIP
OSC
REPEAT
STEP / SLOW
REPEAT A – B
RED / PROGRAM
GREEN / DIGEST
YELLOW / ZOOM
BLUE / BOOKMARK

POWER, AUDIO, MUTE, POP, ARRIBA / MENU, MENU, TOP MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0GOTO, DISPLAY, NETFLIX, ANGLE, SUB, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, RETURN, BACK, HOME, EPG, OPEN /, CLOSE, PAUSE, STOP, REV, VERDE, PLAY, AMARILLO, FWD, AZUL, 2nd, CLEAR, PIP, OSC, REPEAT, STEP / SLOW, SLEEP, REPEAT, INFO, ROJO / PROGRAM, ROJO, VERDE / DIGEST, AMARILLO / ZOOM, AZUL / BOOKMARK, .