FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
⌂
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
CH LIST
RAKUTEN TV
ART
☰
TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
↩
⊞
MEDIA
INFO

GUIDE
YOUTUBE MUSIC
NETFLIX
YOUTUBE
PRIME VIDEO
RED
GREEN
YELLOW
BLUE
FREE
SUBTITLE
PLAY/PAUSE

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, CH LIST, RAKUTEN TV, ART, TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, MEDIA, TV/DTV, INFO, GUIDE, EPG, YOUTUBE MUSIC, FAV, NETFLIX, / NET TV, YOUTUBE, PRIME VIDEO, / SMART, ROJO, VERDE, AMARILLO, AZUL, FREE, SUBTITLE, PLAY/PAUSE, Keys Functions LAYOUT, Code 4315, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .