FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
CH/LIST
DISPLAY
PICTURE
TV / TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
SLEEP
REC. LIST
INDEX
EPG

FAV
HOLD
RED
GREEN
YELLOW
BLUE / SCREEN
SOUND
NICAM / A2
REVEAL
SIZE / ASPECT
SUBTITLE
SKIP NEXT
SKIP PREV
SUBPAGE / TV/RADIO
REPEAT
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, CH/LIST, DISPLAY, PICTURE, TV / TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, REC LIST, TV/DTV, INDEX, INFO, EPG, FAV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL / SCREEN, AZUL, SOUND, NICAM / A2, REVEAL, SIZE / ASPECT, SUBTITLE, SKIP NEXT, SKIP PREV, SUBPAGE / TV/RADIO, REPEAT, PAUSE, STOP, REC, REW, PLAY, FWD, .