FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
OPTION
AUX
BLU – RAY
CBL / SAT
DVD
GAME
INTERNET RADIO
iPod / USB
MEDIA PLAYER
MEDIA SERVER
NETWORK
TUNER
TV AUDIO
SETUP
VOLUME+
VOLUME -
CHANNEL+
CHANNEL -
UP
DOWN
LEFT
RIGHT
ENTER

BACK
SLEEP
INFO
RED / MUSIC
GREEN / MOVIE
YELLOW / PURE
BLUE / GAME
FAV. STATION – 1
FAV. STATION – 2
FAV. STATION – 3
TUNE+
TUNE -
PAGE UP
PAGE DOWN

POWER, MUTE, OPTION, MENU, AUX, BLU, RAY, CBL / SAT, DVD, GAME, INTERNET RADIO, iPod / USB, MEDIA PLAYER, MEDIA SERVER, NETWORK, 0TUNER, / SOURCE, TV AUDIO, SETARRIBA, VOLUME+, VOL+, VOLUME, VOL, CHANNEL+, CHANNEL, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, SLEEP, INFO, ROJO / MUSIC, ROJO, VERDE / MOVIE, VERDE, AMARILLO / PURE, AMARILLO, AZUL / GAME, AZUL, FAV STATION, TUNE+, VOL+, TUNE, PAGE ARRIBA, PAGE ABAJO, .