FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
PLAY LIST
/ PIP
PIP S. LIST
/ PIP SWAP
/ TELETEXT
VOL+
VOL-
CH+
CH-
UP
DOWN
LEFT
RIGHT
OK
/ RECALL
RESOLUTION
TV / RAD.
INFO
EPG

FAV
RED / 🕮
GREEN / 🕮
YELLOW / 🔊
BLUE / ⊞
..... / SUBTITLE
SKIP NEXT
SKIP PREV.
PAGE UP
PAGE DOWN
✓
PAUSE
STOP
REC
REW
PLAY / TIME
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0PLAY LIST, / PIP, PIP S LIST, / PIP SWAP, / TELETEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, / RECALL, BACK, RESOLUTION, SLEEP, TV / RAD, TV/DTV, INFO, EPG, FAV, ROJO /, ROJO, VERDE /, VERDE, AMARILLO /, AMARILLO, AZUL /, AZUL, / SUBTITLE, SKIP NEXT, SKIP PREV, PAGE ARRIBA, PAGE ABAJO, PAUSE, STOP, REC, SHIFT, +ROJO, REW, +VERDE, PLAY / TIME, +AMARILLO, FWD, +AZUL, .