FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
-/--
DISPLAY
SIZE
TEXT
TV / TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
⟲
SLEEP
TV / RADIO
INDEX

EPG
FAV
PICTURE
HOLD
RED
GREEN
YELLOW
BLUE
NICAM / A2
SUBPAGE
CANCEL
REVEAL
PIC. FORMAT
SOUND
SUBTITLE
SKIP NEXT
SKIP PREV
FAV+
FAV-
DVB
LANGUAGE
STOP
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, DISPLAY, SIZE, TEXT, TV / TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, TV / RADIO, TV/DTV, INDEX, INFO, EPG, FAV, PICTURE, / NET TV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, NICAM / A2, SHIF+MUTE, SUBPAGE, CANCEL, REVEAL, PIC FORMAT, SOUND, SUBTITLE, SKIP NEXT, SKIP PREV, FAV+, DVB, LANGUAGE, STOP, REW, PLAY / PAUSE, FWD, .