FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY
MENU
CLR
1/2/3/4/5
6/7/8/9/0
VIDEO OUT
10+
DISPLAY
ZOOM
SETUP
/ SUBTITLE
VOL+
VOL-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
OK
REPEAT
SLEEP
PAL / NTSC
TITLE

/ ANGLE
PROGRAM
OPEN / CLOSE
PAUSE / STEP
STOP
REW
PLAY
FWD
/ AUDIO
/ SEARCH
3D
CARD
SHUFFLE
SLOW
A-B
/ DIMMER
DIGEST
MARK

STANDBY, POWER, MUTE, MENU, CLR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0VIDEO OUT, / AV, 10+, DISPLAY, ZOOM, SETARRIBA, / SUBTITLE, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, REPEAT, BACK, SLEEP, PAL / NTSC, TV/DTV, TITLE, INFO, / ANGLE, EPG, PROGRAM, FAV, OPEN / CLOSE, PAUSE / STEP, STOP, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, / AUDIO, / SEARCH, CARD, / AV, SHUFFLE, SLOW, / DIMMER, DIGEST, MARK, .