FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
HOME
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
BACK
FREEVIEW PLAY
INFO
GUIDE
NETFLIX
YOUTUBE
PRIME VIDEO

RED
GREEN
YELLOW
BLUE
AUDIO
SUBT
PAUSE
STOP
REC
REW
PLAY
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, HOME, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, FREEVIEW PLAY, TV/DTV, INFO, GUIDE, EPG, NETFLIX, / NET TV, YOUTUBE, PRIME VIDEO, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, SUBT, PAUSE, STOP, REC, REW, PLAY, FWD, Keys Functions LAYOUT, Code 4757, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .