FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

I/⏻
🔇
HOME
EXIT
1/2/3/4/5
6/7/8/9/0
/
TITLE LIST
SOCIAL VIEW
DIGITAL / ANALOG
OPTIONS
☰
VOL+
VOL -
/ PROG.+
/ PROG. -
UP
DOWN
LEFT
RIGHT
⊕
RETURN / BACK
DISCOVER
TV / RADIO
/ i+

GUIDE
TV PAUSE
APPS / SEN
RED
GREEN
YELLOW
BLUE
AUDIO
SYNC. MENU
RELATED SEARCH
.....
⟲
i – MANUAL / ?
FOOTBALL
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, MUTE, HOME, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 /, / SOURCE, TITLE LIST, SOCIAL VIEW, DIGITAL / ANALOG, OPTIONS, VOL+, VOL, / PROG+, / PROG, ABAJO, IZQUIERDA, DERECHA, RETURN / BACK, BACK, DISCOVER, SLEEP, TV / RADIO, TV/DTV, / i+, INFO, GUIDE, EPG, TV PAUSE, APPS / SEN, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, SYNC MENU, RELATED SEARCH, MANUAL /, FOOTBALL, FAV, PAUSE, STOP, REC, REW, PLAY, FWD, .