FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
MENU
EPG /
1/2/3/4/5
6/7/8/9/0
SOURCE
ASPECT / 10+
P. STD / →|◪|←
REPEAT /
A-B /
TTX /
VOL+
VOL -
PROGRAM+
PROGRAM -
UP
DOWN
LEFT
RIGHT
OK
/ SUBTITLE
SLEEP
GO TO /
INFO

TITLE / ADD /
MENU / SUB.
RED
GREEN
YELLOW
BLUE
AUDIO / I/II
DVD/FAV SETUP
S. STD / →|♪|←
SLOW /
SKIP NEXT
SKIP PREV
EJECT / EXIT
STOP
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, EPG /, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, SOURCE, ASPECT / 10+, P STD /, REPEAT /, B /, TTX /, VOL+, VOL, PROGRAM+, PROGRAM, ABAJO, IZQUIERDA, DERECHA, / SUBTITLE, BACK, SLEEP, GO TO, TV/DTV, INFO, TITLE / ADD /, EPG, MENU / SUB, FAV, ROJO, VERDE, AMARILLO, AZUL, AUDIO / I/II, DVD/FAV SETARRIBA, S STD /, SLOW /, SKIP, NEXT, PREV, EJECT / EXIT, STOP, REW, PLAY / PAUSE, FWD, .