FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
ATV MENU
EXIT /
1/2/3/4/5
6/7/8/9/0
SOURCE
-/-- / 10+
P. STD / →|◪|←
REPEAT / TIMER /
SUBTITLE /
TTX /
VOL+
VOL-
PROGRAM+
PROGRAM-
UP
DOWN
LEFT
RIGHT
OK
⟲
SLEEP
GO TO / TV.R /
INFO

TITLE / EPG /
MENU / FAV /
RED
GREEN
YELLOW
BLUE
AUDIO / I/II
DVD/DVB SETUP
S. STD / →|♪|←
SLOW / SUB /
SKIP PREV.
SKIP NEXT
EJECT
STOP
REW
PLAY / PAUSE
FWD

POWER, MUTE, ATV MENU, MENU, EXIT /, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / 10+, P STD /, REPEAT / TIMER /, SUBTITLE /, TTX /, VOL+, VOL, PROGRAM+, PROGRAM, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, GO TO / TV, R /, TV/DTV, INFO, TITLE / EPG /, EPG, MENU / FAV /, FAV, ROJO, VERDE, AMARILLO, AZUL, AUDIO / I/II, DVD/DVB SETARRIBA, S STD /, SLOW / SUB /, SKIP PREV, SKIP NEXT, EJECT, STOP, REW, PLAY / PAUSE, FWD, .