FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
/ SOURCE
LIST
▶⏮ / HELP
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
BACK
TIMER
RADIO
i+
GUIDE
MEDIA

RED / A → Z
GREEN / LANG.
YELLOW / S.TITLE
BLUE / A/FOCUS
SKIP NEXT
SKIP PREV
STOP
REC
REW
PLAY
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / SOURCE, / SOURCE, LIST, / HELP, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, TIMER, SLEEP, RADIO, TV/DTV, INFO, GUIDE, EPG, MEDIA, FAV, / NET TV, ROJO / A, ROJO, VERDE / LANG, VERDE, AMARILLO / STITLE, AMARILLO, AZUL / A/FOCUS, AZUL, SKIP NEXT, SKIP PREV, STOP, REC, REW, PLAY, FWD, Keys Functions LAYOUT, Code 1006, 0HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .