FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
MENU
CLEAR
1 / SLEEP
2 / REPEAT
3 / SHUFFLE
4 / SMART EQ
5 / DBB
6 / INCR. SURR.
7 / SAME ARTIST
8 / SAME GAME
9 / RDS/NEWS
0
HOME
MUSIC BROADCAST
MUSIC FOLLOWS ME
VOL+
VOL-
SKIP NEXT
SKIP RPEV.
UP
DOWN
LEFT
RIGHT

OK
VIEW
MARK / UNMARK
STOP
REC
PLAY / PAUSE
🔎 / SEARCH
AUX
HD
MP3 – CD / CD
FM TUNER
SCROLL UP
SCROLL DOWN

POWER, MUTE, MENU, CLEAR, EXIT, 1 / SLEEP, 2 / REPEAT, 3 / SHUFFLE, 4 / SMART EQ, 5 / DBB, 6 / INCR SURR, 7 / SAME ARTIST, 8 / SAME GAME, 9 / RDS/NEWS, 00HOME, MUSIC BROADCAST, MUSIC FOLLOWS ME, VOL+, VOL, SKIP NEXT, SKIP RPEV, ABAJO, IZQUIERDA, DERECHA, VIEW, INFO, MARK / UNMARK, FAV, STOP, REC, ROJO, PLAY / PAUSE, AMARILLO, / SEARCH, AUX, MP3, CD / CD, FM TUNER, SCROLL ARRIBA, SCROLL ABAJO, .