FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
USB
DISPLAY
SCALE
S. MODE
P. MODE
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
🕮
SLEEP
EPG
FAV

AUTO
RED
GREEN
YELLOW / TE/CC
BLUE / NICAM
SKIP NEXT
SKIP PREV
STOP
REC
REW
PLAY/PAUSE
FWD

ORIGINAL, SARRIBAERIOR, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, SOURCE, USB, DISPLAY, SCALE, S MODE, P MODE, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, EPG, FAV, AUTO, / NET TV, ROJO, VERDE, AMARILLO / TE/CC, AMARILLO, AZUL / NICAM, AZUL, SKIP NEXT, SKIP, PREV, STOP, REC, REW, PLAY/PAUSE, FWD, Keys Functions LAYOUT, Code 1852, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .