FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
MENU
DELETE
1/2/3/4/5
6/7/8/9/0
•
HOME
SHUFFLE
SETUP
SUBTITLE
VOLUME+
VOLUME -
PAGE+
PAGE -
UP
DOWN
LEFT
RIGHT
ENTER
↵ / BACK
PB
INFO
ORANGE / ONLINE
LANGUAGE

PURPLE / MUSIC
GREEN / VIDEO
YELLOW / STAGE 6
BLUE / PHOTO
🔎 / SEARCH
SKIP NEXT
SKIP PREV.
⟲ / REPEAT
STOP
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, DELETE, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, HOME, SHUFFLE, SETARRIBA, SUBTITLE, VOLUME+, VOL+, VOLUME, VOL, PAGE+, PAGE, ABAJO, IZQUIERDA, DERECHA, ENTER, / BACK, BACK, TV/DTV, INFO, ORANGE / ONLINE, EPG, LANGUAGE, FAV, PURPLE / MUSIC, ROJO, VERDE / VIDEO, VERDE, AMARILLO / STAGE 6, AMARILLO, AZUL / PHOTO, AZUL, / SEARCH, SKIP NEXT, SKIP PREV, / REPEAT, STOP, REW, PLAY / PAUSE, FWD, SHFIT+AZUL, .