FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
MUTE
POP MENU / MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
MODE
ANGLE
DISPLAY
SOUND MODE
SETUP
SUBTITLE
VOL+
VOL -
SOURCE+
SOURCE -
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
SURROUND
TOP FAV

RED
GREEN
YELLOW
BLUE
AUDIO
SEARCH
SKIP NEXT
SKIP PREV.
REPEAT
OPEN / CLOSE
PAUSE
STOP
REW
PLAY
FWD

STANDBY / ON, POWER, MUTE, POP MENU / MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0MODE, / AV, ANGLE, DISPLAY, SOUND MODE, SETARRIBA, SUBTITLE, VOL+, VOL, SOURCE+, SOURCE, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, SURROUND, EPG, TOP FAV, FAV, ROJO, VERDE, AMARILLO, AZUL, AUDIO, SEARCH, SIFT+EXIT, SKIP NEXT, SKIP PREV, REPEAT, OPEN / CLOSE, PAUSE, STOP, REW, PLAY, SHFIT+AMARILLO, FWD, .