FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
AUDIO
MENU
1/2/3/4/5
6/7/8/9/0
SHUFFLE
DISPLAY
ZOOM
SETUP
SUBTITLE
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
TOP MENU / RETURN
SLEEP
SCAN
ON SCREEN
PROG
DIMMER

PAUSE
STOP
PLAY
ANGLE
REPEAT
A – B

ORIGINAL, SARRIBAERIOR, STANDBY / ON, POWER, AUDIO, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SHUFFLE, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, TOP MENU / RETURN, BACK, SLEEP, SCAN, TV/DTV, ON SCREEN, INFO, PROG, EPG, DIMMER, FAV, PAUSE, STOP, / SMART, PLAY, AMARILLO, ANGLE, REPEAT, Keys Functions LAYOUT, Code 3768, HELP DESK / SARRIBAPORT, infosuperior, electronicscom, COMPATIBLE, DEVICES, VISIT OUR WEBSITE, TO DISCOVER, WWWSARRIBAERIOR, ELECTRONICSCOM, .